

ATEX指令

増圧弁

56-VBA Series


10A~43A



RoHS

II 3G Ex h IIB T6 Gc  
II 3D Ex h IIIC T71°C Dc

## 型式表示方法



## ねじ種類・オプション組合せ表

ボディサイズ	ねじ種類	オプション										標準仕様		
		無記号	G	N	S	GN	GS	LN	LS	GLN	GLS	無記号	-Z	
10A 11A	無記号	●	●	●	●	●	●	●	●	●	●	●	●	—
	F	●	●	●	●	●	●	●	●	●	●	●	●	—
	N	●	●	●	—	●	—	●	—	●	—	●	●	●
	T	●	●	●	—	●	—	●	—	●	—	●	●	●
20A 22A	無記号	●	●	●	●	●	●	●	●	●	●	●	●	—
	F	●	●	●	●	●	●	●	●	●	●	●	●	—
	N	●	●	●	—	●	—	●	—	●	—	●	●	●
	T	●	●	●	—	●	—	●	—	●	—	●	●	●
40A 42A 43A	無記号	●	●	●	●	●	●	●	●	●	●	●	●	—
	F	●	●	●	●	●	●	●	●	●	●	●	●	—
	N	●	●	●	—	●	—	●	—	●	—	●	●	●
	T	●	●	●	—	●	—	●	—	●	—	●	●	●

上記以外の仕様は、標準品VBAシリーズと同一です。  
詳細は[こちら](#)をご覧ください。