

NVB Series ©32, ©40, ©50 @63, ©80, ©100

The Replacement Procedure is on p. 455

Construction



With rod boot



* Replaceable with the rod boot assembly For details on replacement part numbers, refer to page 245.

Component Parts

component arts						
No.	Description	Material	Qty.	Note		
17	Rod seal A		1			
37)	Rod seal B	NBR	1			
38	Piston seal B		1			
39	Cushion seal	Urethane	2			
41)	Cylinder tube gasket	NBR	2			

Lock Unit Replacement

Lock offit neplacement							
Bore size (mm)	Port type	Replacement lock unit part no.					
	Rc	MWB32-UA					
32	NPT	MWB32TN-UA					
	G	MWB32TF-UA					
	Rc	MWB40-UA					
40	NPT	MWB40TN-UA					
	G	MWB40TF-UA					
	Rc	MWB50-UA					
50	NPT	MWB50TN-UA					
	G	MWB50TF-UA					
	Rc	MWB63-UA					
63	NPT	MWB63TN-UA					
	G	MWB63TF-UA					
	Rc	MWB80-UA					
80	NPT	MWB80TN-UA					
	G	MWB80TF-UA					
	Rc	MWB100-UA					
100	NPT	MWB100TN-UA					
	G	MWB100TF-UA					

* For lock unit with a rod boot, add –J to the part number suffix. Example) MWB50-UA-J

Replacement Parts: Seal Kit

Bore size (mm)	Kit no.	Contents
32	MWB32-PS	
40	MWB40-PS	A set of 17 Rod seal A,
50	MWB50-PS	③ Rod seal B,
63	MWB63-PS	39 Piston seal B, 39 Cushion seal, and
80	MWB80-PS	Cylinder tube gasket
100	MWB100-PS	

* Never dissemble the lock unit. It should be replaced as a unit. The seal kit shown above contains the rod seal for the cylinder and lock unit. Order the seal kit suitable for the cylinder bore size.

* The seal kit shown above includes a grease pack. (a32, a40, a50: 10 g, a63, a80: 20 g, a100: 30 g)
Order with one of the following part numbers when only the grease pack is required.

Grease pack part no.: GR-S-010 (10 g), GR-S-020 (20 g)