Type 3 Integrated input-output type

# Fieldbus System (For Input/Output)

# EX600 Series

# Supports digital inputs/outputs, C E CA analog inputs/outputs, and IO-Link units (RoHS)

### O IO-Link unit compatible SI unit

EtherNet/IP™ EtherCAT PROFINET



<Compatible Protocols>
Compatible Protocols>
Compatible Protocols>
Compatible Protocols>
Compatible Protocols>
Compatible Protocols
Com

**IP67** 

# IO-Link unit

- 2 models (port class A and port class B)
- Diagnosis is possible from the upper level communication.
- The data can be accessed from via PC (setting tool).
- Device parameter setting function, Automatic saving/writing

# Self-diagnosis function

Equipped with an input/output open/shortcircuit detection function and an input/output signal ON/OFF counter function

# Web server function\*1

Status checks and forced output are possible via web browser.

# Various connectors available

The following connectors are selectable for the input/output devices: M12 connectors, M8 connectors, D-sub connectors, and spring type terminal blocks.


# Up to 9 units<sup>\*1</sup> can be connected.

Up to 9 units can be connected in any order. \*1 Excludes SI units




29.99

# Can be connected with digital, analog, and IO-Link units



**⊘**SMC



# Connectable Solenoid Valve/Vacuum Unit

Applicable valve		Flow rate characteristics (4/2 $\rightarrow$ 5/3)		Max. number	Power consumption	Applicable
Applicable valve		C [dm³/(s·bar)]	b	of solenoids	[W]	cylinder size
	SY3000	1.6	0.19			ø50
	Y5000	3.6	0.17	32	0.35 (Standard) 0.1 (With power-saving circuit)	ø63
c Sus S	Y7000	5.9	0.20	1	0.1 (with power-saving circuit)	ø80
IP67 *1, *3	SY1000	0.91	0.48		0.2 (With power-saving circuit)	ø40
	SY3000	2.77	0.27	32	0.4 (Standard)	ø50
	SY5000	6.59	0.22	1	0.1 (With power-saving circuit)	ø80
	60700* <sup>2</sup>	0.37	0.39	32	0.35	ø25
	SV1000*2	1.1	0.35		0.6	ø40
	SV2000*2	2.4	0.18	32		ø63
	V3000*2	4.3	0.21	]		ø80
IP67 *1	QC1000	1.0	0.30		0.4 (Standard)	ø40
	QC2000	3.2	0.30	24		ø63
VCCAV	QC4000	7.3	0.38	24	0.95 (Standard)	ø160
V	QC5000	17	0.31	1	0.4 (Low-wattage type)	ø180
Applicable vacuum unit		Nozzle diame [mm]	eter	Max. number of solenoids	Power consumption [W]	Max. vacuum pressure [kPa]
IP40		0.7				
		1.0		10	0.4	01
	ZK2⊟A	1.2		16	0.4	-91
	ł	1.5		1		

\*1 Units with a D-sub connector or spring type terminal block are IP40.

\*2 There are no manifold part number setting for the EX600-SPN3/4/31, EX600-SEN7/8, and EX600-SEC3/4. (Order it separately.)

\*3 The JSY1000 is IP40.




# **O**IO-Link


IO-Link is a communication technology for sensors and actuators that is an international standard, IEC 61131-9.

This technology is used to send/receive device information such as manufacturer, product part number, parameters, and diagnostic data, as well as the control data including ON/OFF signals and measured values of the sensor, by connecting the IO-Link master and device in a 1:1 configuration.

IO-Link enables condition monitoring and error detection of the sensor and equipment, and it can contribute to the reduction of startup labor and recovery time and the realization of preventive and predictive maintenance.



# **IO-Link System Configuration**



#### IO-Link unit

Acts as a gateway between the IO-Link
 communication and the upper level communication

#### IO-Link device

 A sensor/actuator connecting to each port of the IO-Link unit in a 1:1 configuration

#### IODD file

- A file in which device properties and parameters are described
- · Registered to the setting tool
- · Provided by the device manufacturer

#### Communication cable


- A 4-wire or 5-wire general-purpose cable that is the
- same as the existing sensor cable (Unshielded cable) • Max. cable length: 20 m

#### IO-Link setting tool (IO-Link Device Tool)

- Software for the setting and monitoring of an IO-Link unit/device
- \*1 A setting tool compatible with the IO-Link units of every manufacturer is used for the SMC EX600 series IO-Link unit. (IO-Link Device Tool VS-PE (VS or later only) manufactured by TMG Technologie und Engineering GmbH (hereinafter referred to as TMG))


# **IO-Link Interface**


The connecting part between the IO-Link unit and the device is called a "port." Each port can be switched between "IO-Link mode" for digital communication and "standard I/O mode" for conventional contact input/ output.



### 2 types of interfaces

There are two methods for power supply: one is for sensors, and the other is for actuators.






The control power supply wire and signal wire can be connected with one cable. (Mainly for sensors)

The control power supply wire, external power supply wire, and signal wire can be connected with one cable. (Mainly for actuators)

# IO-Link Unit

# Can be connected with digital, analog, and IO-Link unit units

Up to **9** IO-Link units can be connected. (36 IO-Link devices can be connected.) Digital units, analog units, and IO-Link units can be mixed, and up to 9 units can be connected in any order.



Supports both port class A and port class B




For connecting IO-Link sensors Pressure sensors, flow sensors, actuator position sensors, electro-pneumatic regulators, etc.




For connecting IO-Link compatible SI units (for valve driving)

# The data can be accessed from via PC (IO-Link setting tool).



#### Setting screen

Monitoring screen



IO-Link units and IO-Link devices can be set and monitored from a PC without going through a PLC. Process data

- Unit parameters, Device parameters
- Unit information, Device information
- Port diagnosis, Device diagnosis


The IO-Link setting tool is TMG's IO-Link Device Tool.
 It can be downloaded for free from TMG's website. However, to use it for more than 30 days, a license key for the IO-Link Device Tool is required. (Refer to page 1437 for details.)



# Diagnosis function

#### Diagnosis is possible from the upper level communication.

IO-Link unit (port) diagnostic information can be obtained via PLC program or PC (web browser). Device diagnostic information can be obtained via PC (setting tool).



 
 Items of IO-Link unit (port) diagnosis

 Detection of port short-circuit

 Detection of non-connected device

 Detection of misconnected device (check error)

 Notification of port misconfiguration (excessively large input/output data)

 Conditions of diagnostic event (port, device)

 Items of device diagnosis


Diagnostic results (problem phenomenon) received from devices are shown in event codes.

## Device parameter setting function, Automatic saving/writing

#### The parameter setting of devices is possible from the upper level communication.

Parameter setting is possible via PC (setting tool).


It is also possible to use output data or message data via PLC program.



# **EtherNet Fieldbus Functions**


PROFINET (EX600-SPN3/4/31), EtherNet/IP<sup>™</sup> (EX600-SEN7/8), and EtherCAT (EX600-SEC3/4) support the following functions.

### Compatible topologies (Connection configuration)



For ring networks, communication can be continued even if one of the communication cables in the network is disconnected or damaged. As the EX600-SEN7/8 supports Device Level Ring (DLR), and the EX600-SPN3/4/31 supports Media Redundancy Protocol (MRP), the disconnected point can be identified.

\* In order to use DLR or MRP, the PLC must be able to support it.



# ■Supports the QuickConnect<sup>™</sup> function and the Fast Start Up function

# Time from power ON to communication connection

 $10 \text{ s} \rightarrow \textbf{0.5} \text{ s}$ 

In the case of a tool changer, it takes about 10 seconds for communication to be connected in some products after the power to the device installed on the tool is turned ON.


The EX600-SEN7/8 supports the Quick-Connect™ function, and the EX600-SPN3/4 supports the Fast Start Up function, which enables communication connection in only approx. 0.5 s.

\* In order to use the QuickConnect<sup>™</sup> function or the Fast Start Up function, the PLC must be able to support it.

## Built-in web server function

The EX600-SEN7/8, EX600-SPN3/4/31, and EX600-SEC3/4 have a built-in web server function, which enables status checks, parameter settings (EX600-SEN7/8 and EX600-SEC3/4), and forced output of the EX600 using general-purpose web browsers, such as Google Chrome.

Start-up of the system and maintenance can be performed efficiently.




# EX600 **①**

# **PROFINET Technology**

# System Redundancy S2

As the EX600-SPN3/4/31 supports System Redundancy S2, it can continue communication using the backup controller when the primary controller malfunctions. This allows for the prevention of problems caused by unexpected communication interruption.

 $\ast\,$  In order to use System Redundancy S2, the PLC must be able to support this function.



EX600

EX600 
Connection example

Forced output, etc.

# EX600-SPN31 PROFINET/OPC UA

## PC UA server function

As the data communication protocol OPC UA is platform independent, it can be used to improve efficiency and visualization onsite by transmitting operating status, diagnostic information, etc.

It can also communicate with devices using other Fieldbus protocols.

#### Various production equipment status visualization methods Flow, pressure, temperature, and other sensor information can be communicated to the host system via Industrial Ethernet or the OPC UA data communication protocol. Equipment status can be monitored from another location or from outside the office. Host system . . . . . . . . Web server function The operating status can be confirmed via a standard web PC/server SCADA/HMI User cloud browser, eliminating the need for -PLC-dependent software. Via server/Gateway Direct connection User and password Via PLC Via Browser encryption OPC UA direct connection Edge server IoT gateway PC PLC Direct connection PROFI PC UA t HTTPS []N]E]T] . Direct connection 2 Supports secure communication 81 00 0 00 Supports communication methods 10 00.0 with communication encryption and Om username and password 001 authentication requirements SI uni Digital C UA Newly supported functions · · · · Supports the display of hierarchy Pressure switch Ionizer G No Highlight As objects are displayed by unit, equipment Root Objects configuration is easy to understand. > 🗀 Aliases Y 🦂 DeviceSet > 4 0 EX600 System > a 1\_EX600 Digital input unit > a 2\_EX600 Digital output unit > a 3\_EX600 IO-Link master unit Solenoid valve Various switches (Commercially available) > S\_EXED ID-LINE mit > S\_EXED ID-LINE mit > S\_EXED ID-LINE mit > SeviceFeatures > SeviceTopology > NetworkSet > Server Supports the text display of operating status As the unit operating status numerical value is also displayed as text, information is easy to understand. Data Access View Server **Display Name** Value EV600@192.168.0.2 Communication status 1 (Comm ation is established (Idle) EX600@192.168.0.2 Communication EX600@192.168.0.2 Port status info EX600@192.168.0.2 Port status info 4 (Operate) 1 (Deactivated) EX600@192.168.0.2 Port status info 5 (Standard I/O input) EX600/00192.168.0.2 Port status info 6 (Standard I/O output) OPC UA client UAexpert display examples

**SMC** 

**⊘**SMC

# Fieldbus System EX600

#### D-sub connector




SQ series

These units are capable of connection using a D-sub connector. There are three types of units: for digital input, output, and input/output. The digital output unit can be connected with an SMC manifold solenoid valve F kit (D-sub connector).

#### Manifold solenoid valves/Vacuum unit can be connected using a cable with a D-sub connector.

- SY series S0700 series SJ series SV series VQC series VQ series • ZK2 A series
  - JSY series
- \* Please limit the number of valve connections to 16 stations for single and 8 stations for double. Refer to the catalog of each product for pin assignment details.

VVZS3000-21A--X192 (Non-waterproof cable example)



# Spring type terminal block




These terminal block units are compatible with individual wiring configurations. There are three types of units: for digital input, output, and input/output. Wiring connection to a sensor connector box, etc., can be carried out easily using only a flat head screwdriver.



# Digital input unit



This unit is for inputting a digital signal (ON/OFF signal). The signal of a 2-wire/3-wire auto switch attached to the actuator can be acquired to feedback a signal to the PLC. The control signal of an entire system can be managed by a Fieldbus system.






# Analog input/output unit



These units are for inputting or outputting an analog signal (voltage/current). A single unit performs both input and output, allowing feedback control where analog signals are received from a pressure sensor and sent to a pressure controller. Installation space is minimized as well.



# Self-diagnosis function

The following shows examples of the self-diagnosis function.

#### Short/Open-circuit detection

It is possible to detect short or open circuits of input devices such as electronic 2-wire switches and 3-wire switches and output devices such as solenoid valves. The location of the error can be identified by the indicator light and the network.



#### Counter function


It is possible to ascertain the maintenance period and identify the parts that require maintenance by an input and output signal ON/OFF counter function. When the counter function is enabled and a certain number of contact operations is reached, the display of the counter will flash in red.

\* The counter function is not provided with analog units.

### Individual units can be connected and removed one by one.

A unique clamping method is adopted to prevent screws from falling out. Units can be separated easily by loosening the joint bracket. Up to 9 units can be connected in any order.

\* Excludes SI units






# CONTENTS

# Type 3 Integrated input-output type

# Fieldbus System (For Input/Output) *EX600 Series*







p. 140	Б
How to Order	
SI Unit p. 140	
Digital Input Unit ·····p. 140	
Digital Output Unitp. 140	
Digital Input/Output Unit ······p. 140	
Analog Input Unit ·····p. 140	6
Analog Output Unit ······p. 140	
Analog Input/Output Unit ······p. 140	
IO-Link Unit ······ p. 140	
End Plate (D side)p. 140	
Handheld Terminalp. 140	7
Specifications	
All Units Commonp. 140	
SI Unit p. 140	
Digital Input Unit ······p. 141	
Digital Output Unit ······p. 141	
Digital Input/Output Unit ······p. 141	
Analog Input Unit ·····p. 141	
Analog Output Unit ······p. 141	
Analog Input/Output Unit ······p. 141	
IO-Link Unit ······ p. 141	
End Plate ······p. 141	
Handheld Terminalp. 141	
Dimensions ······p. 141	
Parts Descriptionp. 142	
LED Indicator ······· p. 142	3

#### Accessories

<b>O</b> E	End Plate Bracketp.	1427
<b>0</b> \	/alve Plate ······p.	1427
6E	End Plate (U side)p.	1428
<b>4</b> F	Reinforcing Brace p.	1428
68	Seal Cap (10 pcs.)p.	1428
6	Marker (1 sheet, 88 pcs.) ······ p.	1428
ØF	Power Supply Cable (7/8 inch connector)p.	1429
<b>8</b> F	Power Supply Field-wireable	
C	Connector (7/8 inch) ······p.	1429
Ø۶	Power Supply Cable	
(	M12 connector, For EX600-ED2) ······p.	1429
(D) F	Power Supply Cable	
(	M12 connector, For EX600-ED4/5) ······p.	1430
0	Communication Cablep.	1431
ØF	Field-wireable Communication Connector	1435
BI/	/O Cable with Connector, I/O Connectorp.	1436


#### Made to Order

① Ethernet POWERLINK compatible	1438
<ol> <li>Modbus/TCP compatiblep.</li> </ol>	1438
③ CC-Link IE Field compatiblep.	1438
Communication Cablep.	1439

Specific Product Precautions p. 14	40
------------------------------------	----



#### **Parts Structure**



How to Order

SI Unit

EX600-SPR1A



			Specifications
Symbol	Protocol	Output type	Note
PR1A	PROFIBUS DP	PNP (Negative common)	—
PR2A	PROFIBUS DP	NPN (Positive common)	—
DN1A	DeviceNet <sup>®</sup>	PNP (Negative common)	—
DN2A	Deviceivel	NPN (Positive common)	—
MJ1	CC-Link	PNP (Negative common)	—
MJ2 CC-LINK		NPN (Positive common)	—
CF1-X60	CC-Link IE Field	PNP (Negative common)	(Made to order)
EN7	EtherNet/IP™	PNP (Negative common)	IO-Link unit
EN8	Ellenveur	NPN(Positive common)	IO-Link unit
EC3	EtherCAT	PNP (Negative common)	IO-Link unit
EC4	EtherCAT	NPN (Positive common)	IO-Link unit
PN3		PNP (Negative common)	IO-Link unit
PN4	PROFINET	NPN (Positive common)	IO-Link unit
PN31	PROFINET	PNP (Negative common)	IO-Link unit OPC UA server

**SMC** 

	How to Orde	r
Digital Input Unit	EX600-DXP	
	Symbol Description ■ PNP N NPN	Number of inputs, open-circuit detection, and connector Symbol Number of Open-circuit Connector
	N NPN	B         B inputs         No         M12 connector (5 pins) 4 pcs.           C         B inputs         No         M8 connector (3 pins) 8 pcs.           C1         B inputs         Yes         M8 connector (3 pins) 8 pcs.           D         16 inputs         No         M12 connector (2 pins) 8 pcs.           D         16 inputs         No         M12 connector (2 pins) 8 pcs.           F         16 inputs         No         D-sub connector (2 pins)           F         16 inputs         No         Spring type terminal block (32 pins)
Digital Output Unit	EX600-DY P	
	Output type↓ Symbol Description P PNP N NPN	Aumber of outputs and connector     Number of     Connector     Description     B 8 outputs     M12 connector (5 pins) 4 pcs.     E     16 outputs     D-sub connector (25 pins)     F     16 outputs     Spring type terminal block (32 pins)
Digital Input/Output Unit	EX600-DMP	
	Input/Output type ● §mbl Description P PNP N NPN	♦ Number of inputs/outputs and connector         Symbol       Number of outputs         Symbol       Number of outputs         E       8 inputs       outputs         F       8 inputs       8 outputs         Spring type terminal block (32 pins)
Analog Input Unit	EX600- <u>AX A</u>	
	Analog input ↓ ↓ N Sym A	Jumber of input channels and connector           bol         Number of input channels         Connector           1         2 channels         M12 connector (5 pins) 2 pcs.
Analog Output Unit	EX600- <u>AY</u> A	
	Analog output ↓ ↓N Symi A	Number of output channels and connector           Number of output channels         Connector           2 channels         M12 connector (5 pins) 2 pcs.
1406	6	



## Fieldbus System For Input/Output **EX600** Series

How to Order

Analog Input/Output Unit	EX600 – <u>AM</u>		mber of input	/output char	nnels and coni	nector
		Symbol	Number of input channels			
		в	2 channels	2 channels	M12 con (5 pins)	
IO-Link Unit	EX600-LA	B	1			
	- T	P	1			
	Port specification		Number of ports			
	A Port class A	B	4 ports	M12 co	nnector	
	B Port class B		4 ports	(5 pins)	4 pcs.	
	Caution The compatible SI unit models : EtherNet/IPT*: EX600-SEN7/8 PROFINET: EX600-SPN3/4/31 EtherCAT: EX600-SEC3/4	are as	shown below. (f	Refer to page	1485.)	
End Plate (D side)	X600- <u>ED2</u>		2	[	EX600-ED4/5 a not yet UL-con	
	End plate •		Mounting me Symbol De	ethod scription	Not	е
End plate me	ounting position: D side		Nil Without DIN	rail mounting brack	et —	
	Power supply connector			il mounting bracket il mounting bracket		
	ower supply connector Specifications M12 (5 pins) B-coded IN				) is used, the sy same as the D sid	
3 4 M	7/8 inch (5 pins) IN 12 (4/5 pins) A-coded*1 IN/OUT		mounting meth	ou musi de ine	same as the D sid	e.
For M12 For 7/8 inch 5 M	12 (4/5 pins) A-coded*1 IN/OUT					
	pin layout for the "4" and "5" pin ectors is different.					
Refer	to the dimensions on page 1417.					
Handheld Terminal	EX600-HT1	_	-3	[	Handheld term not yet UL-con	
	Versio	n∳	Cable lei	n <b>gth</b> Description		
- Store			Nil 1 3	No cable 1 m 3 m		

# Specifications

#### All Units Common Specifications

ent	Operating temperature range	Operating: -10 to 50°C, Stored: -20 to 60°C
Ē	Operating humidity range	35 to 85% RH (No condensation)
ŝ	Withstand voltage*1	500 VAC for 1 minute between external terminals and FE
Ē	Insulation resistance <sup>*1</sup>	500 VDC, 10 M $\Omega$ or more between external terminals and FE
Environ	Operating temperature range Operating humidity range Withstand voltage <sup>*1</sup> Insulation resistance <sup>*1</sup>	500 VAC for 1 minute between external terminals and FE 500 VDC, 10 M $\Omega$ or more between external terminals and FE

<sup>\*1</sup> Except handheld terminals

#### SI Unit (EX600-SPR A) PROFIBUS

<u> </u>						
	Model	EX600-SPR1A	EX600-SPR2A			
5	Protocol	PROFIBUS DP (DP-V0)				
ation	Device type	PROFIBUS	S DP Slave			
음	Communication speed	9.6/19.2/45.45/93.75/187.5	/500 kbps 1.5/3/6/12 Mbps			
Ē	Configuration file	GSD	file*2			
Communic	Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs)				
Te	rminating resistor	Internally in	plemented			
Int (Po	ernal current consumption ower supply for Control/Input)	80 mA or less				
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)			
-	Number of outputs	32 outputs (8/16/24/32 outputs selectable)				
utput	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)				
5	Power supply	24 VDC, 2 A				
Fail safe HOLD/CLEAR/Forced power		orced power ON				
	Protection	Short-circuit protection				
Er	nclosure	IP67 (Manifold assembly)				
St	andards	CE/UKCA marking, UL (CSA)				
W	eight	30	) g			

\*2 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

#### SI Unit (EX600-SDN A) DeviceNet®

_		EX600-SDN1A	EX600-SDN2A	
-				
	Protocol	DeviceNet®: Volume 1 (Edition		
E	Device type	Communicat		
l₩	Communication speed		500 kbps	
<u>6</u>	Configuration file	EDS file*3		
ommunication	Occupation area (Number of inputs/outputs)	Max. (512 input	ts/512 outputs)	
Cor	Applicable messages	Duplicate MAC ID Check Message, Group 2 Only Unconnected Explicit Message Explicit Message (Group 2), Poll I/O Message (Predefined M/S Connection set)		
	Applicable function	QuickConnect™		
De	viceNet <sup>®</sup> power supply	11 to 25 VDC (Current consumption 50 mA or less)		
Internal current consumption (Power supply for Control/Input)				
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)	
+	Number of outputs	32 outputs (8/16/24/32 outputs selectable)		
utput	Load	Solenoid valve with surge voltage sup	pressor 24 VDC, 1.5 W or less (SMC)	
E	Power supply	24 VD	C, 2 A	
0	Fail safe	HOLD/CLEAR/F	orced power ON	
	Protection	Short-circui	t protection	
Er	closure	IP67 (Manifol	ld assembly)	
St	andards	CE/UKCA mark	king, UL (CSA)	
W	eight	300 g		

\*3 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

#### SI Unit (EX600-SMJD) CC-Link

<u> </u>						
	Model	EX600-SMJ1	EX600-SMJ2			
E	Protocol	CC-Link (Ver. 1.10, Ver. 2.00)				
ij	Station type	Remote De	vice Station			
ŝ	Communication speed	156/625 kbps 2.5/5/10 Mbps				
Ē	Configuration file	CSP+	file*4			
Communication	Occupation area (Number of inputs/outputs)	Max. (512 inputs/512 outputs) 1/2/3/4 stations occupied				
Internal current consumption (Power supply for Control/Input)		75 mA or less				
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)			
+	Number of outputs	32 outputs (8/16/24/32 outputs selectable)				
brt	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC)				
ont	Power supply	24 VD	C, 2 A			
0	Fail safe	HOLD/CLEAR/F	orced power ON			
	Protection	Short-circui	t protection			
En	closure	IP67 (Manifo	ld assembly)			
St	andards	CE/UKCA mar	king, UL (CSA)			
Weight 300 g			0 a			

\*4 The configuration file can be downloaded from the SMC website: https://www.smcworld.com



EX600-SPR



EX600-SDN



EX600-SMJ



# Specifications



EX600-SCF1-X60

	Model	EX600-SCF1-X60*1	
	Protocol	CC-Link IE Field	
	Station type	Intelligent Device Station	
	Communication speed	1 Gbps	
÷	Allowable station number setting	1 to 120	
<u>ca</u>	Allowable network number setting	1 to 239	
S	Transmission method	Cyclic transmission	
E	Configuration file	CSP+ file*2	
Communication	Occupied input size	RX: 32 to 176 bits	
	Occupied input size	RWr: 32 to 608 words	
	Occupied output size	RY: 32 to 176 bits	
	Occupied output size	RWw: 32 to 608 words	
	ernal current consumption	140 mA or less	
(PC	wer supply for Control/Input)		
	Output type	Source/PNP (Negative common)	
	Number of outputs	32 outputs	
Ħ	Load	Solenoid valve with surge voltage suppressor	
Output		24 VDC, 1.0 W or less (SMC)	
0	Power supply	24 VDC, 2 A	
	Fail safe	HOLD/CLEAR/Forced power ON	
	Protection	Short-circuit protection	
Er	nclosure	IP67 (Manifold assembly)	
St	andards	CE/UKCA marking	
W	eight	300 g	

\*1 For details on this product, refer to the SMC website. \*2 The configuration file can be downloaded from the SMC website: https://www.smcworld.com

#### SI Unit (EX600-SEN□) EtherNet/IP™

	Model	EX600-SEN7	EX600-SEN8				
	Durate and	EtherNet/IP™					
	Protocol	(Conformance vers	ion: Composite 18)				
	Communication speed	10/100	) Mbps				
-	Communication method	Full duplex/Half duplex					
ē	Configuration file	EDS	file*3				
ca	IP address setting	SI Unit switch settings:	192.168.0 or 1.1 to 254				
Ē	range	Through DHCP serv	er: Optional address				
Communication		Vendor ID: 7 (SI	MC Corporation)				
5	Device information		nmunication Adapter)				
0		Product of	code: 258				
	QuickConnect	•					
	DLR	•					
	Web server function	•					
10	-Link unit	$\bullet$					
	ernal current consumption ower supply for Control/Input)	120 mA or less					
	Output type	Source/PNP	Sink/NPN				
	Output type	(Negative common)	(Positive common)				
1	Number of outputs	32 οι	itputs				
Output	Load	Solenoid valve with su	rge voltage suppressor				
12	Luau		or less (SMC)				
<b>–</b>	Power supply		C, 2 A				
	Fail safe	HOLD/CLEAR/F	orced power ON				
	Protection		it protection				
Er	closure	IP67 (Manifold assembly)					
St	andards	CE/UKCA mar	king, UL (CSA)				
W	eight	30	0 g				

\*3 The configuration file can be downloaded from the SMC website: https://www.smcworld.com



EX600-SEN7/8

# Specifications



EX600-SEC3/4

#### SI Unit (EX600-SEC ) EtherCAT

<u> </u>	Model				
		EX600-SEC3	EX600-SEC4		
ы.	Protocol	EtherCAT (Conformance Test Record V.2.3.0)			
Configuration file		100 1	Mbps		
		XML	file*1		
ខ	Web server function				
10	Link unit				
	ernal current consumption wer supply for Control/Input)	120 mA or less			
	Output type	Source/PNP (Negative common)	Sink/NPN (Positive common)		
	Number of outputs	32 outputs (8/16/24/32 outputs selectable)			
Output	Load	Solenoid valve with surge voltage sup	pressor 24 VDC, 1.0 W or less (SMC)		
E	Power supply	24 VD	C, 2 A		
	Fail safe	HOLD/CLEAR/F	orced power ON		
	Protection	Short-circuit protection			
En	closure	IP67 (Manifold assembly)			
St	andards	CE/UKCA marking, UL (CSA)			
We	eight	30	Dg		

\*1 The configuration file can be downloaded from the SMC website: https://www.smcworld.com



EX600-SPN3/4/31

#### SI Unit (EX600-SPN ) PROFINET

	Model	EX600-SPN3	EX600-SPN4	EX600-SPN31			
	Protocol	PROFI	PROFINET IO				
	Protocol	(Conforman	ce Class C)	(Conformance Class B)			
5	Communication speed		100 Mbps				
nication	Configuration file		GSDML file*2				
읃	Fast Start Up		)	●* <sup>3</sup>			
屋	(Communication connection time)	(Approx.	500 ms)	(Approx. 1 s)			
Commu	MRP		•				
ပြီ	System Redundancy S2		•				
	Web server function	•					
	OPC UA server function	- •					
10	-Link unit						
	ernal current consumption ower supply for Control/Input)	120 mA or less					
	Output type	Source/PNP	Sink/NPN	Source/PNP			
1	Output type	(Negative common)	(Positive common)	(Negative common)			
utput	Number of outputs		32 outputs				
1	Load	Solenoid valve with surge voltage suppressor 24 VDC, 1.0 W or less (SMC)					
1	Fail safe	HOLD/CLEAR/Forced power ON					
	Protection	Short-circuit protection					
Er	closure	IP67 (Manifold assembly)					
St	andards	CE/UKCA marking, UL (CSA)					
W	eight	300 g					

\*2 The configuration file can be downloaded from the SMC website: https://www.smcworld.com \*3 When the OPC UA server is set to disabled



# Specifications





EX600-DX



#### Digital Input Unit


	Model		EX600-DXPB	EX600-DXNB	EX600-DXPC	EX600-DXNC	EX600-DXPD	EX600-DXND	
	Input type		PNP	NPN	PNP	NPN	PNP	NPN	
	Input connecto	r	M12 (5-pir	n) socket*1	M8 (3-pin	) socket*3	M12 (5-pir	n) socket*1	
	Number of inpu	uts	8 inputs (2 inp	uts/Connector)	8 inputs (1 inp	out/Connector)	16 inputs (2 inp	uts/Connector)	
	Supplied voltage	ge			24 \	/DC			
	Max. supplied current			onnector Unit		onnector /Unit		onnector Unit	
hput	Protection	Protection		Short-circuit protection					
트	Input current (at	24 VDC)	9 mA or less						
	ON voltage		17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)						
	OFF voltage		5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)						
	Open circuit	2 wires	-	_	0.5 mA	/Input*2	-	-	
	detection current	3 wires	-	_	0.5 mA/Co	onnector*2	-	-	
Сι	Current consumption		50 mA	50 mA or less 55 mA or less		70 mA	or less		
Enclosure			IP67 (Manifold assembly)						
Standards			CE/UKCA marking, UL (CSA)						
W	eight		30	0 g	27	5 g	34	0 g	

\*1 M12 (4-pin) connector can be connected.

\*3 When connecting the M8 plug connector, the tightening torque must be 0.2 N·m ±10%. If tightened with an excessive tightening torque, this may cause the connector thread of the unit to break.

Model		EX600-DXPE	EX600-DXNE	EX600-DXPF	EX600-DXNF		
	Input type	PNP	NPN	PNP	NPN		
	Input connector	D-sub sock Lock screw: I	et (25 pins) No.4-40 UNC	Spring type termin	nal block (32 pins)		
	Number of inputs	16 ir	iputs	16 inputs (2 inp	outs x 8 blocks)		
	Supplied voltage		24 \	/DC			
Input	Max. supplied current	2 A/	2 A/Unit		′Block Unit		
	Protection	Short-circuit protection					
	Input current (at 24 VDC)		5 mA or less				
	ON voltage	17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
	OFF voltage	5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V)					
Ap	plicable wire	-	-	0.08 to 1.5 mm <sup>2</sup> (AWG16 to 28)			
Си	irrent consumption	50 mA or less		55 mA	or less		
En	closure	IP40 (Manifold assembly)					
Sta	andards	CE/UKCA marking, UL (CSA)					
We	eight	300 g					

# Specifications



EX600-DY□E EX600-DM□E



EX600-DY□F EX600-DM□F

#### Digital Output Unit

	Model	EX600-DYPB	EX600-DYNB	EX600-DYPE	EX600-DYNE	EX600-DYPF	EX600-DYNF	
	Output type	PNP	NPN	PNP	NPN	PNP	NPN	
	Output connector	M12 (5-pir	M12 (5-pin) socket*1		D-sub socket (25 pins) Lock screw: No.4-40 UNC		Spring type terminal block (32 pins)	
put	Number of outputs	8 outputs (2 out	puts/Connector)	16 ou	Itputs	16 outputs (2 ou	tputs x 8 blocks	
Output	Supplied voltage		24 VDC					
Ĵ	Max. load current			0.5 A/Output 2 A/Unit				
	Protection		Short-circuit protection					
A	pplicable wire	_		_			1.5 mm <sup>2</sup> 6 to 28)	
С	urrent consumption	50 mA or less						
Enclosure		IP67 IP40 (Manifold assembly) (Manifold assembly)						
Standards			CE/UKCA marking, UL (CSA)					
w	eight		300 g					

\*1 M12 (4-pin) connector can be connected.

#### Digital Input/Output Unit

	Model	EX600-DMPE	EX600-DMNE	EX600-DMPF	EX600-DMNF	
In	out/Output type	PNP	NPN	PNP	NPN	
Co	onnector	D-sub sock Lock screw: I		Spring type termin	nal block (32 pins)	
	Number of inputs	8 inputs		8 inputs (2 inp	uts x 4 blocks)	
	Supplied voltage		24 \	/DC		
	Max. supplied current	2 A/	Unit		/Block /Unit	
Protection Sho			Short-circu	it protection		
트	Input current (at 24 VDC)	5 mA or less				
	ON voltage	17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 (At PNP input, between the pin for input terminal and supplied voltage of 0 V)				
	OFF voltage	5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 (At PNP input, between the pin for input terminal and supplied voltage of 0 V)				
	Number of outputs	8 out	tputs	8 outputs (2 outputs x 4 block		
5	Supplied voltage	24 VDC				
Output	Max. load current	0.5 A/Output 2 A/Unit				
	Protection	Short-circuit protection				
A	plicable wire	-	-	0.08 to 1.5 mm <sup>2</sup>	2 (AWG16 to 28)	
Сι	irrent consumption	50 mA	or less	60 mA	or less	
Er	closure	IP40 (Manifold assembly)				
St	andards	CE/UKCA marking, UL (CSA)				
W	eight	300 g				

# Specifications



EX600-AXA

#### Analog Input Unit

Model			EX600	-AXA		
	Input type		Voltage input	Current input		
	Input conn	ector	M12 (5-pin) socket*1			
	Input chan	nel	2 channels (1 cha	annel/Connector)		
	Supplied v	oltage	24 V	/DC		
	Max. suppl	ied current	0.5 A/Co	onnector		
+	Protection		Short-circui	t protection		
nput	Input	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA		
=	signal range	16 bit resolution	-10 to 10 V, -5 to 5 V	-20 to 20 mA		
	Max. rated input signal		±15 V	±22 mA*2		
	Input impedance		100 kΩ	50 Ω		
	Linearity (2	25°C)	±0.05% F.S.			
	Repeatabil	ity (25°C)	±0.15% F.S.			
	Absolute ac	curacy (25°C)	±0.5% F.S.	±0.6% F.S.		
С	urrent consu	Imption	70 mA or less			
Er	Enclosure		IP67 (Manifold assembly)			
St	andards		CE/UKCA marking, UL (CSA)			
w	eight		290	) g		

\*1 M12 (4-pin) connector can be connected.
 \*2 When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.


#### Analog Output Unit

	Mod	el	EX600	)-AYA		
	Output type		Voltage output	Current output		
	Output cor	nnector	M12 (5-pin) socket*3			
	Output cha	nnel	2 channels (1 ch	annel/Connector)		
	Supplied v	oltage	24 \	/DC		
	Max. load o	current	0.5 A/Co	onnector		
Output	Protection		Short-circuit protection			
	Output signal range	12 bit resolution	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA		
	Load impedance		1 kΩ or more	600 Ω or less		
	Linearity (25°C)		±0.05% F.S.			
	Repeatabil	ity (25°C)	±0.15% F.S.			
	Absolute ac	curacy (25°C)	±0.5% F.S.	±0.6% F.S.		
Сι	urrent consu	Imption	70 mA or less			
Enclosure			IP67 (Manifold assembly)			
Standards			CE/UKCA marking, UL (CSA)			
w	eight		29	0 g		

\*3 M12 (4-pin) connector can be connected.



# Specifications




EX600-AMB

#### Analog Input/Output Unit

	Model		D-AMB			
	Input type	Voltage input	Current input			
	Input connector	M12 (5-pin) socket*1				
	Input channel	2 channels (1 ch	annel/Connector)			
	Supplied voltage	24 \	/DC			
	Max. supplied current	0.5 A/Co	onnector			
1.2	Protection	Short-circu	it protection			
Input	Input signal range	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA			
	Max. rated input signal	15 V	22 mA*2			
	Input impedance	100 kΩ	250 Ω			
	Linearity (25°C)	±0.05	% F.S.			
	Repeatability (25°C)	±0.15% F.S.				
	Absolute accuracy (25°C)	±0.5% F.S.	±0.6% F.S.			
	Output type	Voltage output	Current output			
	Output connector	M12 (5-pin) socket*1				
	Output channel	2 channels (1 channel/Connector)				
	Supplied voltage	24 VDC				
1	Max. load current	0.5 A/Connector				
Output	Protection	Short-circuit protection				
ō	Output signal range	0 to 10 V, 1 to 5 V, 0 to 5 V	0 to 20 mA, 4 to 20 mA			
	Load impedance	1 kΩ or more	600 Ω or less			
	Linearity (25°C)	±0.05	% F.S.			
	Repeatability (25°C)	±0.15°	% F.S.			
	Absolute accuracy (25°C)	±0.5% F.S.	±0.6% F.S.			
С	urrent consumption	100 mA	or less			
E	nclosure	IP67 (Manifold assembly)				
S	tandards	CE/UKCA mar	king, UL (CSA)			
W	/eight	30	0 g			


\*1 M12 (4-pin) connector can be connected.
 \*2 When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.

# Specifications



EX600-LDB1

	Model	EX600	-LAB1	EX600-LBB1	
IO-Link version		Version 1.1			
IO-Link port class		Class A		Class B	
Communication speed		COM1 (4.8 kBaud) COM2 (38.4 kBaud) COM3 (230.4 kBaud) * Changes automatically according to the connected device			
N	umber of IO-Link ports			4	
Compatible SI unit (Protocol)		EX600-SEN7/8 (EtherNet/IP™) EX600-SPN3/4/31 (PR0FINET) EX600-SEC3/4 (EtherCAT)			
ly current	Device power supply (L+)	0.5 A/Co (2 A/		0.5 A/Connector (1 A/Unit)	
Max. supply current	External power supply (P24)			1.6 A/Connector (3 A/Unit)	
	Pin no.	2	4	4	
	Input type	PNP			
Input	Protection	Short-circuit protection			
Ĕ	Rated input current	Approx. 2.5 mA		Approx. 5.8 mA	
	ON voltage	13 V or more			
	OFF voltage	8 V or less			
	Pin no.		4		
Ħ	Output type	PNP			
Output	Max. load current (C/Q line)	0.25 A/Output (Supplied from the power supply for control/input)			
	Protection		Short-circu	it protection	
С	urrent consumption	50 mA or less			
Er	nclosure	IP67 (Manifold assembly)			
St	andards	CE/UKCA marking, UL (CSA)			
w	eight	320 g			



EX600-ED3-

End Plate

IO-I ink I Init

		Model	EX600-ED2-	EX600-ED3-	EX600-ED4/5-		
ŝ	Power supply	PWR IN	M12 (5-pin) plug	7/8 inch (5-pin) plug	M12 (4-pin) plug		
ations	connector	PWR OUT	-	—	M12 (5-pin) socket		
specific	Rated	Power supply for control/input	24 VDC ±10%				
	voltage	Power supply for output	24 VDC +10/-5%				
Power	Rated	Power supply for control/input	Max. 2 A	Max. 8 A	Max. 4 A		
ዳ	current	Power supply for output	Max. 2 A	Max. o A	Max. 4 A		
Enclosure			IP67 (Manifold assembly)				
Standards*1			CE/UKCA marking, UL (CSA)				
Weight			170 g	175 g 170			

\*1 The EX600-ED4/5- is not compliant with UL (CSA) standards.

#### Handheld Terminal

Model	EX600-HT1A-	
Power supply	Power supplied from SI unit connector (24 VDC)	
Current consumption	50 mA or less	
Display	LCD with backlight	
Connection cable	Handheld terminal cable (1 m ··· EX600-AC010-1, 3 m ··· EX600-AC030-1)	
Enclosure	IP20	
Standards*1	CE/UKCA marking	
Weight	160 g	


\*
1 The handheld terminal is not compliant with UL (CSA) standards.
2 Cannot be used with the EX600-SEN7/8, EX600-SPN3/4/31, EX600-SEC3/4, and EX600-L




EX600-HT1A-

# **\$SMC**

### Dimensions



#### Dimensions



# M12 4-pin plug, A-coded

Configuration	EX600-ED4 (Pin arrangement 1)		EX600-ED5 (Pin arrangement 2)	
Conngulation	Pin no.	Description	Pin no.	Description
$3 \sim 2$	1	24 V (for control/input)	1	24 V (for output)
60	2	24 V (for output)	2	0 V (for output)
69	3	0 V (for control/input)	3	24 V (for control/input)
4 1	4	0 V (for output)	4	0 V (for control/input)

# M12 5-pin socket, A-coded


Configuration	EX600-ED4 (Pin arrangement 1)		EX600-ED5 (Pin arrangement 2)	
Configuration	Pin no.	Description	Pin no.	Description
1 2	1	24 V (for control/input)	1	24 V (for output)
60	2	24 V (for output)	2	0 V (for output)
( %)	3	0 V (for control/input)	3	24 V (for control/input)
4 3	4	0 V (for output)	4	0 V (for control/input)
. 5 -	5	Unused	5	Unused


# M12 5-pin plug, B-coded

Configuration	EX600-ED2		
Conliguration	Pin no.	Description	
	1	24 V (for output)	
<sup>2</sup>	2	0 V (for output)	
5 f = 0)	3	24 V (for control/input)	
	4	0 V (for control/input)	
	5	FE	


## Dimensions

#### End Plate (D side) EX600-ED3





5.5



#### Power supply connector PWR: 7/8 inch 5-pin plug


Pin no.	Description
1	0 V (for output)
2	0 V (for control/input)
3	FE
4	24 V (for control/input)
5	24 V (for output)
	Pin no. 1 2 3 4 5


## Fieldbus System For Input/Output **EX600** Series

#### Dimensions


#### **Digital Unit**


















EX600-DX










EX600-DXDD



EX600-DX EX600-DY EX600-DM F









# Dimensions


### Analog Unit


EX600-AXA EX600-AYA






#### EX600-AMB










# IO-Link Unit

EX600-LAB1 EX600-LBB1









## Fieldbus System For Input/Output **EX600** Series

### **Parts Description**

#### SI Unit







EX600-SEN7/8 EX600-SPN3/4/31 EX600-SEC3/4

No.	Name	Use
1	Status indication LED	Displays unit status
2	Indication cover	Open for setting the switch.
3	Indication cover set screw	Loosen for opening the indication cover.
4	Connector (BUS OUT)	Connects to the fieldbus output cable $(SPEEDCON)^{*1}$
5	Marker groove	Can be used to mount a marker
6	Connector (PCI)	Connects to the handheld terminal cable (SPEEDCON)
7	Valve plate mounting holes	Fixes a valve plate in place
8	Valve plate mounting groove	Inserts a valve plate
9	Joint bracket	Links units to one another
10	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power
11	Connector (BUS IN)	Connects to the cable for fieldbus input (SPEEDCON)*1
12	MAC address name plate	Displays a unique 12-digit MAC address for each SI unit
13	Seal cap	Mounted on the connectors (BUS OUT and PCI) at the time of shipment


\*1 The EX600-SEN7/8, EX600-SPN3/4/31, and EX600-SEC3/4 are not SPEEDCON compatible.


**Digital Unit** 






No.	Name	Use
1	Status indication LED	Displays unit status
2	Connector	Connects with input or output devices (Only the EX600-D B and EX600- DX D are SPEEDCON compatible.)
3	Marker groove	Can be used to mount a marker
4	Lock screw	Secures the D-sub connector in place (No.4-40 UNC)
5	Joint bracket	Links units to one another
6	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power









### **Parts Description**


### Analog Unit






No.	Name	Use	
1	Status indication LED	Displays unit status	
2	Connector	Connects with input or output devices (SPEEDCON)	
3	Marker groove	Can be used to mount a marker	
4	Joint bracket	Links units to one another	
5	Connector for unit (Plug)	Transmits signals to the neighboring unit and supplies power	


**IO-Link Unit** 




No. Name Use 1 Status indication LED Displays unit status Connects with IO-Link, input, or output 2 Connector devices (SPEEDCON) 3 Marker groove Can be used to mount a marker 4 Joint bracket Links units to one another Connector for unit Transmits signals to the neighboring 5 (Plug) unit and supplies power

### End Plate





No.	Name	Use
1	Power connector (PWR IN)	Supplies power to the unit and/or input/ output device (Only the EX600-ED2/ED4/ ED5-I is SPEEDCON compatible.)
2	Fixing hole for direct mounting	Connects directly to equipment
3	Fixing hole for DIN rail	Converts to manifold or for DIN rail mounting
4	FE terminal	Used for grounding Ground this terminal securely to improve noise immunity.
5	Connector (Unused) Power connector (PWR OUT)	Supplies power to the device on the downstream side





# Fieldbus System For Input/Output **EX600 Series**


# LED Indicator

PORT-1

Communication state

. D

6




PORT-2

Communication state

C

ത


### **LED Indicator**






### Fieldbus System For Input/Output **EX600** Series

### LED Indicator




### **LED Indicator**



**SMC** 

# EX600 Series Accessories



### End Plate Bracket

This bracket is used for the end plate of DIN rail mounting.



### EX600-ZMA2

Enclosed parts Round head screw (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs. EX600-ZMA3 (Specialized for SY series)

Enclosed parts Round head screw with washer (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs.

**2** Valve Plate

### EX600-ZMV1

### Enclosed parts

Round head screw (M4 x 6) 2 pcs. Round head screw (M3 x 8) 4 pcs.




EX600-ZMV2 (Specialized for SY series)

Enclosed parts Round head screw (M4 x 6) 2 pcs. Round head screw (M3 x 8) 2 pcs.

**SMC** 

### Send Plate (U side)

The end plate is for use when the manifold valve is not connected.



### Reinforcing Brace

This bracket is used on the bottom of the unit at the intermediate position for connecting 6 units or more.

\* Be sure to attach this bracket to prevent connection failure between the units caused by deflection.





### Seal Cap (10 pcs.)

Be sure to mount a seal cap on any unused I/O connectors. Otherwise, the specified enclosure cannot be maintained.









### Marker (1 sheet, 88 pcs.)

The signal name of I/O device and each unit address can be entered and mounted on each unit.







#### Dever Supply Cable (M12 connector, For EX600-ED4/5) \* The shape of the M12 connector is A-coded (Normal key).



**SMC** 




#### Communication Cable




• Cable length (L)		
005	500 mm	
010	1000 mm	
020	2000 mm	
030	3000 mm	
050	5000 mm	
100	10000 mm	

Item		Specifications
Cable O.D.		ø7.7 mm
Conductor nominal	Data pair	0.5 mm <sup>2</sup> /AWG20
cross section	Drain	0.34 mm <sup>2</sup> /AWG22
Wire O.D. (Including insulator)		2.55 mm
Min. bending radius (Fixed)		77 mm




### Communication Cable



#### EX9-AC 005 DN-SSPS (With connector on both sides (Socket/Plug))

• Cable length (L)		
005	500 mm	
010	1000 mm	
020	2000 mm	
030	3000 mm	
050	5000 mm	
100	10000 mm	


Item		Specifications
Cable O.D.		ø6.7 mm
Conductor nominal	Power pair	0.34 mm <sup>2</sup> /AWG22
cross section	Data pair	0.25 mm <sup>2</sup> /AWG24
Wire O.D.	Power pair	1.4 mm
(Including insulator)	Data pair	1.95 mm
Min. bending radius (Fixed)		67 mm




#### EX9-AC 005 DN-SAPA (With angled connector on both sides (Socket/Plug))

• Cable length (L)		
005	500 mm	
010	1000 mm	
020	2000 mm	
030	3000 mm	
050	5000 mm	
100	10000 mm	

Item		Specifications
Cable O.D.		ø6.7 mm
Conductor nominal	Power pair	0.34 mm <sup>2</sup> /AWG22
cross section	Data pair	0.25 mm <sup>2</sup> /AWG24
Wire O.D.	Power pair	1.4 mm
(Including insulator)	Data pair	1.95 mm
Min. bending radius (Fixed)		67 mm







Communication Cable


### Communication Cable

## For EtherCAT<sup>®</sup> For PROFINET For EtherNet/IP™


### EX9-AC 005 EN-PSPS (With connector on both sides (Plug/Plug))








#### Field-wireable Communication Connector



For PROFIBUS DP PCA-1075531






Applicubic	Oubic
Item	Specifications
Cable O.D.	4.0 to 8.0 mm
Wire gauge (Stranded wire cross section)	0.14 to 0.75 mm <sup>2</sup> /AWG26 to 18 (Solid cable/Flexible cable) 0.08 to 0.5 mm <sup>2</sup> /AWG28 to 20 (With ferrule)

### I/O Cable with Connector, I/O Connector

#### For details, refer to the Web Catalog


To details, refer to the web catalog.				
Name	Use	Part no.	Description	
Cable with	Cable with connector	For sensor	PCA-1557769	Cable with M12 connector (4 pins/3 m)
connector		PCA-1557772	Cable with M8 connector (3 pins/3 m)	
	Field-wireable connector	PCA-1557730	Field-wireable connector (M8/3 pins/Plug/Piercecon® connection)	
Field-wireable connector		PCA-1557743	Field-wireable connector	
		PCA-155775	PCA-1557756	(M12/4 pins/Plug/QUICKON-ONE connection/SPEEDCON)
Y connector For sensor	PCA-1557785	Y connector (2 x M12 (5 pins)-M12 (5 pins)/SPEEDCON)		
	PCA-1557798	Y connector (2 x M8 (3 pins)-M12 (4 pins)/SPEEDCON)		

\* When using the Y connector, connect it to the connector on the I/O unit through the sensor cable (PCA-1557769) with the M12 connector.




### For IO-Link Unit

EX9-AC 005 -SSPS (With connector on both sides (Socket/Plug))




### I/O Cable with Connector, I/O Connector



#### **IO-Link Device Tool License Key**

#### USB dongle EX9-ZSW-LDT1

9



 The IO-Link Device Tool V5-PE (V5 or later only) manufactured by TMG is required for setting IO-Link devices.

The IO-Link Device Tool can be downloaded for free from TMG's website. However, to use it for more than 30 days, a license key for the IO-Link Device Tool is required.





## EX600 Series **Specific Product Precautions**

Be sure to read this before handling the products. Refer to page 7 for safety instructions and pages 15 to 17 for fieldbus system precautions.

#### Mounting

## A Caution

- 1. When handling and assembling units, do not touch the sharp metal parts of the connector or plug.
- 2. When connecting six stations or more, be sure to use the intermediate reinforcing brace (EX600-ZMB1 or EX600-ZMB2).

#### **Operating Environment**

## A Caution

1. Select the proper type of enclosure according to the operating environment.

IP65/67 is achieved when the following conditions are met.

- 1) Provide appropriate wiring between all units using electrical wiring cables, communication connectors and cables with M12 connectors.
- 2) Appropriately mount each unit and valve manifold.
- 3) Be sure to mount a seal cap on any unused connectors.

If using in an environment that is exposed to water splashes, please take measures such as using a cover.

When the enclosure is IP40, do not use in an operating environment or atmosphere where it may come in contact with corrosive gas, chemical agents, seawater, water, or water vapor. When connected to the EX600-DDDE or EX600-DDF, manifold enclosure is IP40.

Also, the handheld terminal conforms to IP20, so prevent foreign matter from entering inside, and water, solvent or oil from coming in direct contact with it.

#### Adjustment / Operation

## **Warning**

#### <Handheld Terminal>

1. Do not apply pressure to the LCD.

There is a possibility of the crack of LCD and injuring.

2. The forced input/output function is used to change the signal status forcibly. When operating this function, be sure to check the safety of the surroundings and installation.

This may cause injuries or equipment damage.

3. Incorrect setting of parameters can cause a malfunction. Be sure to check the settings before use

This may cause injuries or equipment damage.

## A Caution

#### <Handheld Terminal>


1. Do not press the setting buttons with a sharp pointed object.

This may cause damage or equipment failure.

2. Do not apply excessive load and impact to the setting buttons.

This may cause damage, equipment failure or malfunction.

When the order does not include the SI unit, a valve plate which connects the manifold and SI unit, is not mounted. Use attached valve holding screws and mount the valve plate. (Tightening torgue: 0.6 to 0.7 N·m)



#### ■Trademark

1440

DeviceNet® is a registered trademark of ODVA. Inc.

EtherNet/IP<sup>®</sup> is a registered trademark of ODVA. Inc.

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Modbus® is a registered trademark of Schneider Electric, licensed to the Modbus Organization, Inc.

